



Troxler Electronic Laboratories, Inc.

PO Box 12057 • 3008 Cornwallis Rd. • Research Triangle Park, NC 27709

Tel: (919) 549-8661 • Fax: (919) 549-0761 • web: www.troxlerlabs.com

CALIBRATE DEPTH STRIP

- 1) From the “**READY**” screen, press **{SHIFT}{DEPTH}**.
- 2) Select Option **{2}** “**CALIBRATE**”.
- 3) Position the source rod in the “**SAFE**” position. Press **{ENTER}**.
- 4) The gauge calibrates the depth strip. It then indicates that the depth strip is in the automatic mode and returns to the “**READY**” screen.